

Camera Name	File Format
Adobe Digital Negative	DNG
AVT Dolphin F-201C	RAW
AVT Oscar F-510C	RAW
AVT Oscar F-810C	RAW
Canon EOS-1D	TIF
Canon EOS-1D Mark II	CR2
Canon EOS-1Ds	TIF
Canon EOS-1Ds Mark II	CR2
Canon EOS 5D	CR2
Canon EOS 10D	CRW
Canon EOS 20D	CR2
Canon EOS 300D	CRW
Canon EOS 350D	CR2
Canon EOS D2000C	TIF
Canon EOS D30	CRW, THM
Canon EOS D60	CRW
Canon EOS Digital Rebel	CRW
Canon EOS Digital Rebel XT	CRW
Canon EOS Kiss Digital	CRW
Canon PowerShot 600	CRW
Canon PowerShot A5	CRW
Canon PowerShot A5 Zoom	CRW
Canon PowerShot A50	CRW
Canon PowerShot G1	CRW
Canon PowerShot G2	CRW
Canon PowerShot G3	CRW
Canon PowerShot G5	CRW
Canon PowerShot G6	CRW
Canon PowerShot Pro1	CRW
Canon PowerShot Pro70	CRW
Canon PowerShot Pro90 IS	CRW
Canon PowerShot S30	CRW
Canon PowerShot S40	CRW
Canon PowerShot S45	CRW
Canon PowerShot S50	CRW
Canon PowerShot S60	CRW
Canon PowerShot S70	CRW
Casio EX-P600	RAW
Casio EX-P700	RAW
Casio EX-S100	RAW
Casio EX-Z50	RAW
Casio EX-Z55	RAW
Casio QV-2000UX	RAW
Casio QV-3000EX	RAW
Casio QV-3500EX	RAW
Casio QV-4000	RAW
Casio QV-5700	BAY
Casio QV-R51	BAY
Casio Exlim Pro505	RAW
Casio Exlim Pro600	RAW
Casio Exlim Pro700	RAW
Contax N Digital	RAW
Creative PC-CAM 600	RAW
Epson R-D1	RAW
Foculus 531C	RAW

Fuji FinePix E550	RAF
Fuji FinePix F700	RAF
Fuji FinePix F710	RAF
Fuji FinePix F800	RAF
Fuji FinePix F810	RAF
Fuji FinePix S2 Pro	RAF
Fuji FinePix S3 Pro	RAF
Fuji FinePix S20 Pro	RAF
Fuji FinePix S5000	RAF
Fuji FinePix S5100	RAF
Fuji FinePix S5200	RAF
Fuji FinePix S5500	RAF
Fuji FinePix S7000	RAF
Fuji FinePix S9000	RAF
Fuji FinePix S9500	RAF
Imacon Ixpress 16-MegaPixel	RAW
Imacon Ixpress 22-MegaPixel	RAW
ISG 2020x1520	RAW
Kodak DC20	K25
Kodak DC25	K25
Kodak DC40	KDC
Kodak DC50	KDC
Kodak DC120	KDC
Kodak DCS315C	TIF
Kodak DCS330C	TIF
Kodak DCS420	TIF
Kodak DCS460	TIF
Kodak DCS460A	TIF
Kodak DCS520C	TIF
Kodak DCS560C	TIF
Kodak DCS620C	TIF
Kodak DCS620X	TIF
Kodak DCS660C	TIF
Kodak DCS660M	TIF
Kodak DCS720X	DCR
Kodak DCS760C	DCR
Kodak DCS760M	DCR
Kodak DCS Pro 14N	DCR
Kodak DCS Pro 14Nx	DCR
Kodak DCS Pro SLR/c	DCR
Kodak DCS Pro SLR/n	DCR
Kodak EOSDCS1	TIF
Kodak EOSDCS3B	TIF
Kodak KAI-0340	DCR
Kodak NC2000F	TIF
Kodak P850	DCR
Kodak PB645C	DCR
Kodak PB645H	DCR
Kodak PB645M	DCR
Kodak ProBack	DCR
Konica KD-400Z	RAW
Konica KD-510Z	RAW
Leaf Aptus 17	RAW
Leaf Valeo 11	RAW
Leaf Valeo 22	RAW
Leaf Volare	RAW

Leica DIGILUX 2	RAW
Leica Digital Module R	DNG
Logitech Fotoman Pixtura	RAW
Minolta DiIMAGE 5	MRW
Minolta DiIMAGE 7	MRW
Minolta DiIMAGE 7i	MRW
Minolta DiIMAGE 7Hi	MRW
Minolta DiIMAGE A1	MRW
Minolta DiIMAGE A2	MRW
Minolta DiIMAGE A200	MRW
Minolta DiIMAGE G400	MRW
Minolta DiIMAGE G500	MRW
Minolta DiIMAGE G600	MRW
Minolta DiIMAGE Z2	MRW
Minolta Dynax/Maxxum 5D	MRW
Minolta Dynax/Maxxum 7	MRW
Minolta Dynax/Maxxum 7D	MRW
Nikon D1	NEF
Nikon D1H	NEF
Nikon D1X	NEF
Nikon D2H	NEF
Nikon D2HS	NEF
Nikon D2X	NEF
Nikon D50	NEF
Nikon D70	NEF
Nikon D70s	NEF
Nikon D100	NEF
Nikon D200	NEF
Nikon E700	NEF
Nikon E800	NEF
Nikon E880	NEF
Nikon E900	NEF
Nikon E950	NEF
Nikon E990	NEF
Nikon E995	NEF
Nikon E2100	NEF
Nikon E2500	NEF
Nikon E3700	NEF
Nikon E4300	NEF
Nikon E4500	NEF
Nikon E5000	NEF
Nikon E5400	NEF
Nikon E5700	NEF
Nikon E8400	NEF
Nikon E8700	NEF
Nikon E8800	NEF
NuCore	BMQ
NuCore RAW	RAW
Olympus C70Z	ORF
Olympus C740UZ	ORF
Olympus C770UZ	ORF
Olympus C5050Z	ORF
Olympus C5060WZ	ORF
Olympus C7000Z	ORF
Olympus C8080WZ	ORF
Olympus E-1	ORF

Olympus E-10	ORF
Olympus E-20	ORF
Olympus E-20N	ORF
Olympus E-20P	ORF
Olympus E-300	ORF
Olympus E-500	ORF
Panasonic DMC-FZ30	RAW
Panasonic DMC-LC1	RAW
Panasonic DMC-LX1	RAW
Pentax *ist D	PEF
Pentax *ist DL	PEF
Pentax *ist DS	PEF
Pentax Optio 33WR	PEF
Pentax Optio S	PEF
Pentax Optio S4	PEF
Phase One H10	PEF
Phase One H20	PEF
Phase One H25	PEF
Phase One LightPhase	RAW
Phase One P20	RAW
Phase One P25	RAW
Pixelink A782	RAW
Polaroid x530	RAW
Rollei d530flex	RDC
RoverShot 3320af	RAW
Sigma SD9	X3F
Sigma SD10	X3F
Sinar	CS1
SMaL Ultra-Pocket 3	RAW
SMaL Ultra-Pocket 4	RAW
SMaL Ultra-Pocket 5	RAW
Sony DSC-F828	SRF
Sony DSC-R1	SRF
Sony DSC-V3	SRF
STV680 VGA	RAW